

Philips Signage Touch Screen User Guide

Getting Started:

- Check contents upon unpacking your Touch Screen Monitor:
 - Monitor w/Integrated Touch Screen
 - Video Cable
 - Power Cable
 - Remote Control
- Connect video cable between Computer and Monitor.
- Secure cable to ports by tightening set screws to receptacle.
- Insert Power Cord into Monitor and plug into Grounded A/C Power source.
- Connect USB cable from Monitor to Computer USB port.
- You are now ready to start using your Touch Screen Monitor.

PHILIPS

SignageSolutions

For assistance with this Touch Screen monitor, please call our Customer Care Center at 800-224-7788 8:00 am until 9:00 pm Monday through Friday. Or by email at philips-cs@tosystems.com.



Touch Screen Use

Calibration:

- Your touchscreen is HID Compliant (Plug and Play). You do not need to install software or calibrate the touch screen.



Returns cannot be accepted without original accessories and packaging

Care and Cleaning

Keep Touch Screen Clean For Optimal Use:

- Use a LCD or TV glass cleaner to clean touch screen.
- Spray solution onto clean soft cloth then wipe the surface. Spraying cleaning solution directly onto the monitor may damage the unit.
- Use circular motion to avoid smudges and streaks.
- DO NOT USE any chemical solvents such as an Acidic, or Alkali solution.

